

ISO 13628-8 Class 1-4 (API 17D) Heavy Duty Torque Tool.



DESCRIPTION

This torque tool has been specifically developed to provide the highest level of performance. It has integral torque and turns counting sensors. When matched with a FORUM supplied torque tool control manifold, it can provide precise feedback on torque response of any subsea operation. These can alternatively be utilised by connecting a FORUM Universal Subsea Display (supplied), which would give a visual read-out of live torque feedback and turns count.

The tool conforms to the ISO 13628-8 Fig 18 Class 1-4 bucket interface used extensively in the subsea industry for valve overrides operated by ROV. The tool has latching wings allowing the tool to hold on to the interface. The latching wings are hydraulically driven forward and spring retracted. Thus in the case of a loss of hydraulic power the wings will release. The tool uses a high specification drive motor for consistent torque output characteristics, even if used with direct hydraulic pressure control without the feedback sensor. The motor shares casing oil with the gearbox therefore avoiding the need for a separate compensator.

Note that for applying torques less than 108Nm (80 ft lbs) the class 1&2 tool is recommended.

FEATURES

ISO 13628-8 Fig 18 (API 17D) Class 1-4

Max Torque 2,700 Nm (2,000 ft lbs)

Dual range

Dual Sensor Electronic Turns Counter

Internal Strain Gauge

Latching Wings

Supplied in offshore suitable transit case

ISO 13628-8 Class 1-4 (API 17D) Heavy Duty Torque Tool.

SPECIFICATIONS

Torque Interface:	ISO 13628-8 fig 18 Class 1-4
Torque Range:	405-2700Nm (300-2000 ft lbs) (80cc motor fitted) 81-405Nm (60-300 ft lbs) (12.5cc motor fitted)
Motor Size:	12.5cc nominal and 80cc nominal
Latching Strength:	1 tonne @ 160 Bar
Weight (Air/Water):	45/35kg (98/77 lbs)
Hydraulic:	Mineral Oil (Tellus 32)
Electrical Connector:	8 Pin Burton
Sensors:	Dual Sensor Inductive Turns count sensor Internal Strain Gauge

WHAT'S IN THE BOX

Torque Tool.
Class 1 & 2 Socket (11/16" Sq)
Class 3 socket (1-1/8" Sq)
Class 4 socket (1-1/2" Sq)
JIC Hose Set
Low range motor
Turns and torque Display
8 Pin Burton Dummy
Operations & Maintenance Manual.

PART NUMBERS & OPTIONS

TX00100-580-00	Torque Tool System with USD, sockets, case, hoses, handle.
TX00100-570-00	Spares Kit, Torque Tool and USD components.
TX00100-570-01	Spares Kit, Torque Tool only
A019-958-152/2	Surface Verification Unit.
A019-958-601	Subsea Verification Unit.
TL0017-0000-00	Flying Lead Tool
A286-001-050/04	Torque Tool Control System. (alternative to USD)
A019-959-150	17H (High Torque) Nose Adapter.
A019-959-400	Petrobras Nose Adapter Kit .

